


**Adaptive Cruise Control , (8T4)**

From January 2011

**Audi**

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





Control Module for Adaptive Cruise Control, Control Module 2 for Adaptive Cruise Control, Image Processing Control Module

- J104 ABS Control Module
- J428 Control Module for Adaptive Cruise Control
- J533 Data Bus on Board Diagnostic Interface
- J850 Control Module 2 for Adaptive Cruise Control
- J851 Image Processing Control Module
- ST1 Fuse Panel 1
- SB7 Fuse 7 (On Fuse Panel B)
- T8k 8-Pin Connector
- T8l 8-Pin Connector
- T12i 12-Pin Connector
- T32b 32-Pin Connector
- T38a 38-Pin Connector
- T47 47-Pin Connector

- 55 Ground Connection near ABS Control Module
- 390 Ground Connection 25 (in Main Wiring Harness)
- B280 Positive Connection 4 (15a) (in Main Wiring Harness)

- \* Refer to Applicable Wiring Diagram for Fuse Positions
- \*2 Depending on Equipment
- \*3 Refer to the Applicable Driver Assistance Systems Front Camera Wiring Diagram
- \*4 Data Bus Wire (Flexray Bus)
- \*5 From June 2014

- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink